



WARNING!
 THE CONNECTOR OF THE GAS INJECTOR A
 MUST CORRESPOND TO THE BLUE WIRE
 OF THE PETROL CUT-INJECTOR CABLE.
 THE WIRES TO INTERRUPT ARE
 INJECTORS NEGATIVE WIRES.